

JT EATON™

EARTH ANCHOR

BAIT STATION SECURING SYSTEM



1. Choose location to insert EARTH ANCHOR. Insert Pounding Rod into anchor and pound stake in. Apply a drop of oil or spray some silicone in the hole to aid in removal of the rod. Twisting the rod also aids in the rod removal.



2. Leave an adequate amount of cable to insert "T" through 1/2" hole in bottom of bait station.



3. Properly inserted EARTH ANCHOR shown in a JT EATON™ #910TP STRONGBOX™ Bait Station (far left) and in a RODENT ROCK™ Bait Station (right).

FAMILY OWNED AND OPERATED SINCE 1932

JT EATON™

1.800.321.3421

www.jteaton.com